

## Reservedeler synSupport/Nordic Eye

HMS-Artnr	Kategori	Beskrivelse	Post	Lev.art.nr
	220390	Adapter Compact+	1A	BP6020701
	220390	Bæreveske Compact+	1A	BP6020702
	220390	Hovedkort Compact 4 HD	1A	BP6020711
	220390	Lade-kort Compact 4 HD	1A	BP6020712
	220390	TFT-LCD-display 4,3" Compact+, 4 HD	1A	BP6020713
	220390	Stativ Compact 4 HD	1A	BP6020714
	220390	Batteripakke Compact 4 HD, 5 HD, 7 HD	1A/1B	BP6020715
	220390	Strømforsyning 5V/ 2A Compact+, 4 HD, 5 HD	1A	BP6020716
	220390	Bæreveske Compact 4 HD	1A	BP6020717
	220390	Bæreveske Compact 5 HD	1A	BP6020721
	220390	TFT-LCD-display 5" Compact 5 HD	1A	BP6020722
	220390	Hovedkort Compact 5 HD	1A	BP6020723
	220390	Lade-kort Compact 5 HD	1A	BP6020724
	220390	Sony 8Mpx med linse Compact 5 HD, 7 HD	1A/1B	BP6020725
	220390	Lade-kort Compact 7 HD	1B	BP6020731
	220390	TFT-display 7" refleksfritt Compact 7 HD	1B	BP6020732
	220390	Hovedkort refleksfritt Compact 7 HD	1B	BP6020733
	220390	Strømforsyning 12V/ 2A Compact 7 HD	1B	BP6020734
	220390	Bæreveske Compact 7 HD	1B	BP6020735
	220390	Stativ ClearView C	3A/3B/3C/3D/3E	BP6010001
	220390	XY-bord og Compact-brett ClearView C	3A/3B/3C/3D/3E	BP6010002
	220390	Elektronikk-boks One	3A	BP6010003
	220390	Elektronikk-boks HD	3B	BP6010004
	220390	Elektronikk-boks Speech	3C/3D/3E	BP6010005
	220390	Betjeningspanel ClearView C	3B/3C/3D/3E	BP6010006
	220390	Compact-brett ClearView C	3A/3B/3C/3D/3E	BP6010007
	220390	Displayfeste 21,5" og 24" ClearView C	3B	BP6010010
	220390	Betjeningspanel ClearView One	3A	BP6010011
	220390	Displayfeste Speech ClearView C	3C/3D/3E	BP6010012
	220390	Monitor 21,5" ClearView C	3A	BP6010013
	220390	Minitor 24" ClearView C	3B	BP6010014
	220390	Monitor Speech ClearView C	3C/3D/3E	BP6010015
	220390	Speech Module ClearView C	3C/3D/3E	BP6010016
	220390	Toppdeksel og skjerm 4,3" TFT Looky4	1A	BP6020601
	220390	Bakdeksel Looky4	1A	BP6020602
	220390	Batteri Li-Ion 3,7V 2500mA Looky4	1A	BP6020603
	220390	Håndtak og batteriholder Looky4	1A	BP6020604
	220390	Hovedkort Looky4	1A	BP6020605
	220390	Kamera Looky4	1A	BP6020606
	220390	Lader for Looky4	1A	BP6020608
	220309	USB-kabel A->microB	1A	BP6020609

## Reservedeler synSupport/Nordic Eye

220390	Bæreveske	1A	BP6020607
220390	Lader for Mercury 5	1C	BP6020051
220390	Batteri for Mercury 5	1C	BP6020052
220390	Bæreveske Mercury 5	1C	BP6020053
220390	Monitor 24"	3A / 3B	BP6010550
220390	XY Bord komplet JAZZ	3A / 3B	BP6010551
220390	Power Supply JAZZ	3A / 3B	BP6010552
220390	Monitor 22"	3A / 3B	BP6010553
220390	Kamera HD inkl. print og linse	3A / 3B	BP6010554
220390	Ledning, 10-pin, flad, for kamera	3A / 3B	BP6010555
220390	Gasdæmper, JAZZ	3A / 3B	BP6010556
220390	Panel 4 knapp	3A / 3B	BP6010557
220390	Print Control Interface (internt)	3A / 3B	BP6010558
220390	Print LED med 1 diode	3A / 3B	BP6010559
220390	Print 3 pos. omskifter for JAZZ panel	3A / 3B	BP6010560
220390	Print 10K Alps potmeter	3A / 3B	BP6010561
220390	Kontakt On/Off m/diode 2knapp	3A / 3B	BP6010562
220390	Kontakt 2knapp JAZZ u/holddefunktion	3A / 3B	BP6010563
220390	Knap Sort, nylon	3A / 3B	BP6010564
220390	Kabel Y-ledning, 2 meter	3A / 3B	BP6010565
220390	Kamera SONY FHD 20xZoom, m/Filter	4A	BP6010566
220390	Power Supply IBIS FHD	4A	BP6010567
220390	Kontakt Slimline Kipafbryder	4A	BP6010568
220390	Ledning, 30 pin, flad, 60cm, FHD kamera	4A	BP6010569
220390	Print FHD	4A	BP6010570
220390	Print LED med 1 diode	4A	BP6010571
220390	Betjeningsboks MINI	4A	BP6010572
220390	Kabel HDMI han - HDMI mini han, 2m, IBIS FHD	4A	BP6010573
220390	Kabel USB 3 type A han - micro B han, 1,8m, IBIS FHD	4A	BP6010574
220390	Panel 2 knapp	3A / 3B	BP6010575
220390	Camera FHD 1080p i-See Acuity	3A/3B/3C/3D	BP6010401
220390	Hovedkort i-See Acuity	3A/3B/3C/3D	BP6010402
220390	OCR-kort i-See Acuity	3C/3D	BP6010403
220390	SingleTouch TFT Monitor 22" i-See Acuity	3A/3B	BP6010404
220390	MultiTouch TFT Monitor 22" i-See Acuity	3C/3D	BP6010405
220390	SingleTouch TFT Monitor 24" i-See Acuity	3A/3B	BP6010406
220390	MultiTouch TFT Monitor 24" i-See Acuity	3C/3D	BP6010407
220390	Betjeningspanel i-See Acuity	3A/3B/3C/3D	BP6010408
220390	Strømforsyning i-See Acuity	3A/3B/3C/3D	BP6010409
221890	Eliminator Milestone 212 Ace, 312 Ace	12D/12E	BP4002101
221890	Batteripakke Milestone 212 Ace	12D	BP4001801
221890	Batteripakke Milestone 312 Ace	12E	BP4002115
221890	Høytaler Milestone 212 Ace	12D	BP4001802
221890	Høytaler Milestone 312 Ace	12E	BP4002116
221890	Skinnetui Milestone 212 Ace, 312 Ace	12D/12E	BP40037
221890	USB-kabel Milestone, Plectalk A->miniB	12D/12E/12F	BP4002102
221890	SD-minnekort 8GB Milestone, Plectalk	12D/12E/12F	BP4002103
221890	Strømforsyning Plectalk Poesi II, Linio	12A/12B/12C	BP4021806
221890	Hovedkort Plectalk Poesi II	12A	BP4021801
221890	Hovedkort Plectalk Linio	12B/12C	BP4021701

Reservedeles synSupport/Nordic Eye

221890	Høytaler Plectalk Poesi II, Linio	12A/12B/12C	BP4021802
221890	Strømforsyning Plectalk Pocket, Linio Pocket	12F	BP4021310
221890	CD-drive Plectalk Poesi II, Linio	12F	BP4021810
221890	Hodetelefon Philips HL-145	12A/12B/12C	BP42550
221890	Batteri Plectalk Poesi II, Linio	12A/12B/12C	BP4021805
221890	Batteri Plectalk Pocket, Linio Pocket	12F	BP4021308
221890	Skinnetui Plectalk Pocket, Linio Pocket	12F	BP4021312
223090	Strømforsyning ClearReader+ 20V, 2A	13C/13D	BP6005001
223090	Batteri ClearReader+, 14,8V, 2,6Ah	13C/13D	BP6005002
223090	IO-kort ClearReader+	13A/13B/13C/13	BP6005003
223090	Hovedkort ClearReader+	13A/13B/13C/13	BP6005004
223090	Kort Kontrol-panel ClearReader+	13A/13B/13C/13	BP6005005
223090	Kontroll-panel u/kort ClearReader+	13A/13B/13C/13	BP6005006
223090	Kamera-modul ClearReader+	13A/13B/13C/13	BP6005007
223090	Minnekort Flash 4GB	13A/13B/13C/13	BP6005008
223090	Posisjonerings-matte ReadEasy Move 2	13A/13B	BP6005021
223090	Hodetelefoner ReadEasy Move 2	13A/13B	BP6005022
223090	Bæreeske ReadEasy Move 2	13A/13B	BP6005023
223090	Dokument-kamera A4 5Mpx HD ReadEasy Move 2	13A/13B	BP6005024
223090	Hovedkort ReadEasy Move 2	13A/13B	BP6005025
223090	CPU Hovedkort ReadEasy Move 2	13A/13B	BP6005026
223090	RAM-modul ReadEasy Move 2	13A/13B	BP6005027
223090	SSH ReadEasy Move 2	13A/13B	BP6005028
223090	Strømforsyning 12V 5A ReadEasy Move 2	13A/13B	BP6005029
223990	Høyre kort Alva BC680	9A	BP3099901
223990	Venstre kort Alva BC680	9A	BP3099902
223990	Batteri-kort Alva BC680, USB 640	7A/9A	BP3099903
223990	Bæreeske Alva BC680	9A	BP3099904
223990	Power-kort Alva BC640	7A/7C/9A	BP3099905
223990	Batteri-kort Alva BC640	7A/7C/9A	BP3099906
223990	Strømforsyning BC640 5V-1600mA	7A/7C/9A	BP3099907
223990	Batteripakke 3,7V Alva BC640	7A/7C/9A	BP3099908
223990	Punktcelle Alva	7A/7C/9A	BP3099909
223990	Bæreeske Alva BC640, USB 640 Comfort	7A	BP3099910
223990	Celle leselist Seika Mini, Mini24, 5, 6 Pro, 80	6C/7A/7C/9A	BP3099801
223990	Celle-kort Seika Mini, Mini24, 5, 6 Pro, 80	6C/7A/7C/9A	BP3099802
223990	Batteri Seika Mini, Mini24, 5, 6 Pro	6C/7A/7C	BP3099803
223990	Hoved- og power-kort Seika Mini, Mini24	6C/7C	BP3099804
223990	Markørhenter-kort Seika Mini, Mini24	6C/7C	BP3099805
223990	Hoved-kort Seika 5, Seika 6 Pro	7A/7C	BP3099806
223990	Power-kort Seika 5, Seika 6 Pro	7A/7C	BP3099807
223990	Markørhenter-kort Seika 5, 6 Pro	7A/7C	BP3099808
223990	Hovedkort Seika 80	9A	BP3099809
223990	Power-kort Seika 80	9A	BP3099810
223990	Markørhenter-kort Seika 80	9A	BP3099811
223990	USB-strømforsyning Seika 5V-1000mA	6C/7A/7C	BP3099812
223990	Bæreeske Seika Mini	6C	BP3099813
223990	Bæreeske Seika Mini24	7C	BP3099814
223990	Bæreeske Seika 5	7A	BP3099815
223990	Bæreeske Seika 6 Pro	7C	BP3099816

## Reservedeler synSupport/Nordic Eye

	223990	USB-kabel mini-B	6A/7A/7C/9A	BP3099817
	223990	Minnekort micro-SD 8GB	6C/7C	BP3099818
	220390	Hovedkort Traveller	2A	BP6010020
	220390	Kamera-kort Traveller	2A	BP6010021
	220390	Kamera m/kabel Traveller	2A	BP6010022
	220390	Front deksel Traveller	2A	BP6010023
	220390	TFT-skjerm Traveller	2A	BP6010024
	220390	Bezel Traveller	2A	BP6010025
	220390	Batteripakke Traveller	2A	BP6010025
	220390	Bæreeveske Traveller	2A	BP6010026
	220390	Strømforsyning Traveller	2A	BP6010027
	220390	Nettledning Traveller	2A	BP6010028