

Tilbehør
Comfort Audio AS

HMS-Artnr	Kategori	Beskrivelse	Leverandørens artnr
136014	221890	Halsslynge Duett	F00369
158782	221890	Hodetelefon MyLink	052-3394
160738	221890	Øreplugger Digisystem	F00352
169959	221890	Strømforsyning Roger DigiMaster 5000/7000 (19V, 3,42A)	052-3141
170010	221890	Adapter Cinch audiokabel Comfort Audio	052-0371
185210	221890	Musikkhalsslynge Comfort Audio	F00373
195140	221890	Audio/TV-kabel Digisystem	F00119
195347	221890	Veggfeste Roger DigiMaster 5000/7000	052-3428
196001	221890	Halsslynge Duett kort	F00710
196002	221890	Halsslynge Duett lang	F00709
198601	221890	Lydkabel Mikro Comfort Audio USB	043-3066
200042	221890	Tilkobler Roger Wall Pilot	052-3115
217180	221890	Ladestasjon Roger 4 enheter m/strømforsyning	055-3010
217183	221890	Mikrofon EasyBoom m/jack 3,5 mm	055-3009
217184	221890	Stativ mikrofon Pass-around	005-3121
233249	221890	Belteklemme til Roger Touchscreen Mikrofon	004-4031
233250	221890	Veske mikrofon Roger Touchscreen	017-3272
233251	221890	Etui Roger Pen	017-3275
233252	221890	Pose Roger Clip-On	017-3278
233253	221890	Pose mikrofon Roger Touchscreen	017-3310
233254	221890	Veske mikrofon Pass-around	017-3313
233255	221890	Skjermbeskyttelse mikrofon Roger Touchscreen	017-3323
233256	221890	Veske mikrofon Roger Table	017-4004
233257	221890	Audiosplitter Stereo Comfort Audio	038-3107
233258	221890	Registreringskabel Comfort Audio	043-3070
233259	221890	Skall Farge Roger Focus Pure transparent	048-3001-13
233260	221890	Skall Farge Roger Focus Sand beige	048-3001-P1
233261	221890	Skall Farge Roger Focus Amber beige	048-3001-P2
233262	221890	Skall Farge Roger Focus Sandalwood	048-3001-P3
233263	221890	Skall Farge Roger Focus Chestnut	048-3001-P4
233264	221890	Skall Farge Roger Focus Silver gray	048-3001-P6
233265	221890	Skall Farge Roger Focus Velvet black	048-3001-P8
233266	221890	Skall Farge Roger Focus Ruby	048-3001-P9
233267	221890	Skall Farge Roger Focus Petrol	048-3001-Q1
233268	221890	Skall Farge Roger Focus Electric green	048-3001-Q2
233269	221890	Skall Farge Roger Focus Caribbean pirate	048-3001-Q3
233270	221890	Skall Farge Roger Focus Dragon orange	048-3001-Q4
233271	221890	Skall Farge Roger Focus Vanity pink	048-3001-Q5
233272	221890	Skall Farge Roger Focus Blue lagoon transparent	048-3001-Q6
233273	221890	Skall Farge Roger Focus Royal purple transparent	048-3001-Q7
233274	221890	Skall Farge Roger Focus Precious pink	048-3001-T3
233275	221890	Transportveske Roger DigiMaster 5000/7000	052-3124-0000001
233276	221890	Mottaker CI Roger 14 Brown	052-3222-D02L0

Tilbehør
Comfort Audio AS

233277	221890	Mottaker CI Roger 14 White	052-3222-D02L8
233278	221890	Mottaker CI Roger 14 Black	052-3222-D02L9
233279	221890	Mottaker CI Roger 14 Beige	052-3222-D02M1
233280	221890	Mottaker CI Roger 14 Charcoal	052-3222-D02M2
233281	221890	Mottaker CI Roger 14 Mocka	052-3222-D02T1
233282	221890	Mottaker CI Roger 14 Smoke	052-3222-D02T2
233283	221890	Mottaker CI Roger 17 SandBeige	052-3235-D02P1
233284	221890	Mottaker CI Roger 17 Chestnut	052-3235-D02P4
233285	221890	Mottaker CI Roger 17 Silver Grey	052-3235-D02P6
233286	221890	Mottaker CI Roger 17 Velvet Black	052-3235-D02P8
233287	221890	Mottaker CI Roger 17 Ruby	052-3235-D02P9
233288	221890	Mottaker CI Roger 17 Petrol	052-3235-D02Q1
233289	221890	Mottaker CI Roger 17 Electric Green	052-3235-D02Q2
233290	221890	Mottaker CI Roger 17 Caribbean Pirate	052-3235-D02Q3
233291	221890	Mottaker CI Roger 17 Dragon Orange	052-3235-D02Q4
233292	221890	Mottaker CI Roger 17 Vanity Pink	052-3235-D02Q5
233293	221890	Mottaker CI Roger 17 Alpine White	052-3235-D02XN
233294	221890	Mottaker CI Roger 17 Princess Pink	052-3235-D02XP
233295	221890	Kasse Wall Pilot	052-3242
233296	221890	Beskyttelses/festedeksel Roger 14	055-3014
233297	221890	Beskyttelsesetui Roger Touchscreen Mikrofon	055-3021
233298	221890	Ladestasjon Charging Rack Roger 16-enheter	F01062
217182	221890	Ladekoffert Roger Charging Case	F01061
195335	221890	Gulvstativ til Roger Digimaster 5000/7000	052-3164
195345	221890	Audiokabel Comfort Audio I100	052-0359