

20-9988 Reservedeler - Picomed

HMS-Artnr	Beskrivelse	Leverandørens artnr
286308	Armlene PU ers sport Neatech Xtreme el hø	194003
286309	Armlene PU ers sport Neatech Xtreme el ve	194004
286310	Armlenestøtte ers sport Neatech Xtreme el	194039
286311	Batteri ers sport Neatech Xtreme el 12v 50Ah	194005
286348	Beskyttelse hjul ers sport Neatech Xtreme el	194010
286379	Brakett armlene ers sport Neatech Xtreme el standard nedre	194042
286312	Brakett Joystick ers sport Neatech Xtreme el std	194024
286326	Bryter kjølevifte ers sport Neatech Xtreme el	194018
286327	Dekk drivhjul ers sport Neatech Xtreme el	194008
286328	Deksel ers sport Neatech Xtreme el	194015
286349	Drivhjul Komplette ers sport Neatech Xtreme el	194006
286329	Elektronikk Power Modul Rnet ers sport Neatech Xtreme el	194026
286305	Ers sport Neatech Xtreme el sb30-36 sd34-46 rh43-48	190001
286306	Ers sport Neatech Xtreme el sb36-42 sd34-46 rh53-58	190002
286307	Ers sport Neatech Xtreme el sb42-48 sd34-46 rh53-58	190003
286337	Fotplate hel 36cm ers sport Neatech Xtreme el	194028
286338	Fotplate hel 40cm ers sport Neatech Xtreme el	194029
286339	Fotplate hel 42cm ers sport Neatech Xtreme el	194030
286340	Fotplate hel 50cm ers sport Neatech Xtreme el	194031
286343	Gassfjær ers sport Neatech Xtreme el	194033
286344	Gassfjær Support ers sport Neatech Xtreme el	194034
286347	Hendel hovedsikring ers sport Neatech Xtreme el	194023
286345	Hendel låsebrakett armlene ers sport Neatech Xtreme el	194041
286346	Hendel tiltfunksjon ers sport Neatech Xtreme el	194035
286366	Hovedsikring ers sport Neatech Xtreme el	194021
286367	Hovedsikring PCB Sikring ers sport Neatech Xtreme el	194022
286424	Individuell tilpasning timepris ers sport Neatech Xtreme el elektrisk sport stol	192002
286368	Joystick Rnet ers sport Neatech Xtreme el	194025
286369	Kjølevifte ers sport Neatech Xtreme el	194017
286370	Kjølevifte ers sport Neatech Xtreme el m/monteringsplate	194016
286371	Lader ers sport Neatech Xtreme el	194027
286372	Lager gaffel svinghjul ers sport Neatech Xtreme el	194014
286374	Låsebrakett armlene ers sport Neatech Xtreme el	194040
286375	Låsepinne ryggør ers sport Neatech Xtreme el	194037
286376	Låsesystem fotplate ers sport Neatech Xtreme el	194032
286377	Motor ers sport Neatech Xtreme el hø	194019
286378	Motor ers sport Neatech Xtreme el ve	194020
286380	Polster armlene ers sport Neatech Xtreme el	194038
286422	Reisetid timepris ers sport Neatech Xtreme el elektrisk sport stol	192005
286423	Reparasjon timepris ers sport Neatech Xtreme el elektrisk sport stol	192004
286387	Ryggør ramme 36cm ers sport Neatech Xtreme el	194045
286388	Ryggør ramme 42cm ers sport Neatech Xtreme el	194046
286389	Ryggør ramme 48cm ers sport Neatech Xtreme el	194047
286396	Sidebøyle ers sport Neatech Xtreme el diam32x5,8	194009
286397	Sidestøtte armlene ers sport Neatech Xtreme el	194043
286414	Slange drivhjul ers sport Neatech Xtreme el	194007
286418	Støtfanger bak ers sport Neatech Xtreme el u/svinghjul	194044
286350	Svinghjul bak ers sport Neatech Xtreme el komplett m/gaffel	194012
286352	Svinghjul ers sport Neatech Xtreme el komplett	194013
286351	Svinghjul foran ers sport Neatech Xtreme el komplett m/gaffel	194011
286419	Teleskopør ryggør ramme ers sport Neatech Xtreme el	194036
286425	Tilpasning timepris ers sport Neatech Xtreme el elektrisk sport stol	192003
286420	Trekk rygg Bek Round ers sport Neatech Xtreme el	194002
286421	Trekk rygg Bek Shift ers sport Neatech Xtreme el	194001
286426	Utprøving enhetspris ers sport Neatech Xtreme el elektrisk sport stol	192001